## **Tips for Buffers Settings on the FireStation**

The following equation is used to calculate the audio latency of the mLAN driver

Send = (Buffer Length) x (Buffer) + (ASIO Buffer Length) Receive = (ASIO buffer length) x 1

## There are 3 locations on your CPU were you can adjust the buffer settings

- 1) The Send (out of CPU) side of the mLAN control panel.
- 2) The Receive (in of CPU) side of the mLAN control panel
- 3) The Preferred buffer setting in the mLAN ASIO control panel ALWAYS ADJUST STEP 3 LAST

------Here are some rules to know------

1) Always adjust the buffers length to multiples of ten.

Example 1: 2 buffers at 10 millsec. Or 2 buffer at 20 millsec Example 2: 5 buffers at 10 millsec. Or 6 buffers at 30 millsec

- 2) Never set the ASIO control panels preferred buffer setting below the Receive buffer length setting of the mLAN control panel
- 3) Adjust the buffers in the mLAN control panel 1st then adjust the ASIO buffers to match. *Always set ASIO setting last*.
- 4) Always click <u>SET</u> on the control panel and then <u>apply</u> on your patch bay after making any changes to the buffer setting.
- 5) Recording at 24 bits does lower your latency

- 6) Latency is a problem shared by every CPU and every professional sound card. Every studio is unique. Learn your systems limits and strong points.
- 7) When playing software synths with a midi controller you must decrease the latency of mLAN to the lowest setting in order to get a note or sound to play in time with the track. Also, you should try not enabling the inputs (receive side).
- 8) Many tricks can be done to your Operating system to lower latency. Ask your local computer geek, or read PC magazine, Wired, Computer world, etc.; and never forget the web has many forums out there to help. The best site for XP is *pcaudiolabs.com*

However, perform the following at your own risk; many CPU and operating system changes can help your performance, but some can also be detrimental. Always make changes one-step at a time. This helps to understand which adjustment did or didn't work. Never change the buffer settings, install more RAM, and adjust the operating system at the same time.

- 9) The buffer setting for receive (right side) should always be set to 20 which is the max allowed. Latency related to receive (right side) is not affected by mLAN buffers.
- 10) SEND = (Outs of the CPU) left side of control panel RECEIVE = (In of the CPU) right side of the control panel
- 11) XP users only (very important)
  The Firestation mLAN interface runs as a service on XP.
  You need to tune the machine for best performance on background services. Instructions on how to do this are as follows:
  - 1. Right click my computer...
  - 2. Choose properties which is the bottom choice
  - 3. Next click on the advanced tab....
  - 4. Now click the settings button under *performance...*
  - 5. Click the advanced tab in this window...
  - 6. Set processor scheduling for BACKGROUND SERVICES..

## Also in this performance section you can change the visual settings to <u>ADJUST FOR BEST PREFORMANCE</u>

This is a good starting point for systems, which are 800 MHz, and above:

SEND RECEIVE ASIO

2 buffers 20 buffers 10 milliseconds

10 milliseconds 10 milliseconds

LINKS:

PCAUDIOLABS.COM PRESONUS.COM

E-mail: FSTECH@presonus.com